

Farbübersetzung RAL zu AMANN ISACORD

Hinweis: alle Farben sind nur Farbvorschläge!



RAL	ISACORD
1000	0761
1001	0851
1002	0532
1003	0702
1004	0702
1005	0704
1006	0704
1007	0800
1011	0832
1012	0221
1013	0870
1014	0761
1015	0761
1016	(0501)
1017	(0811)
1018	0310
1019	0934
1020	(0552)
1021	0311
1023	0311
1024	0532
1026	(6010)
1027	0546
1028	0800
1032	(0506)
1033	0800
1034	1030
2000	1102
2001	1332
2002	(1301)
2003	1102
2004	1304
2005	1306
2007	(1120)
2007	(1120)
2008	1200
2009	1304
2010	1114
2011	1102
2012	1430
3000	1704
3001	1902
3002	1902
3003	(1913)
3004	1912
3005	2115
3007	(1366)
3009	(1514)

RAL	ISACORD
3011	1913
3012	(1551)
3013	(1902)
3014	1540
3015	2155
3016	1335
3017	(1921)
3018	1805
3020	1704
3022	1600
3024	(1306)
3026	(1306)
3027	2101
3031	1725
4001	2810
4002	2011
4003	2520
4004	2333
4005	2920
4006	2504
4007	(2711)
4008	2600
4009	(2764)
4010	2520/2300
5000	(3732)
5001	4133
5002	3335
5003	(3323)
5004	3344
5005	(3622)
5007	3810
5008	3666
5009	(4133)
5010	3622
5011	3554
5012	3815
5013	3323
5014	3953
5015	(3902)
5017	(3902)
5018	(4610)
5019	(3902)
5020	4515
5021	4425
5022	3353
5023	(3631)
5024	./.

Farbübersetzung RAL zu AMANN ISACORD

Hinweis: alle Farben sind nur Farbvorschläge!



RAL	ISACORD
6000	5233
6001	5643
6002	(5643)
6003	0465
6004	5374
6005	5335
6006	(5866)
6007	5866
6008	6156
6009	(5555)
6010	5633
6011	(5743)
6012	5374
6013	0453
6014	6156
6015	1375
6016	(5422)
6017	5633
6018	(5531)
6019	5650
6020	5866
6021	5822
6022	1876
6024	5422
6025	5933
6026	5005
6027	(4430)
6028	5555
6029	5422
6032	5422
6033	(4520)
6034	(4430)
7000	3852
7001	0108
7002	0674
7003	0128
7004	1972
7005	0111
7006	0776
7008	0747
7009	1375
7010	1375
7011	0132
7012	0132
7013	1874
7015	0132
7016	4174
7021	4174
7022	1375
7023	0128
7024	0132
7026	4174

RAL	ISACORD
7030	0152
7031	0132
7032	0151
7033	0463
7034	0873
7035	3770
7036	1972
7037	0108
7038	0124
7039	1874
7040	0131
7042	(0152)
7043	(4174)
7044	0151
7045	4073
7046	0108
7047	0150
8000	0763
8001	0932
8002	1342
8003	1134
8004	(1115)
8007	0933
8008	(0933)
8011	1355
8012	(1355)
8014	0945
8015	(1355)
8016	1346
8017	1366
8019	(1876)
8022	./.
8023	1115
8024	0933
8025	(1055)
8028	(1055)
9001	0101
9002	0184
9003	0010
9004	0020
9005	0020
9006	0131
9006	IM 0511
9007	0152
9007	IM (1874)
9010	(0101)
9011	0020
9016	0010
9017	0020
9018	3770